


ITEM	part	Description
1	06582	SANDER ADAPTER
2	06583	COLLET BODY
3	06528	COLLET (1/4")
3	06529	COLLET (1/8")
3	06530	COLLET (3/16")
3	06540	COLLET (3MM)
3	06541	COLLET (6MM)
4	06516	COLLET NUT
5	06578	BEARING RETAINER
6	06591	OUTPUT SHAFT
7	06507	BALL BEARING
8	06646	SPIRAL BEVEL GEAR SET
9	06505	NEEDLE BEARING
10	06637	ANGLE HEAD ASSEMBLY (INCLUDES FIGURES 9 + 11)
11	06523	GREASE FITTING
12	06653	ANGLE HEAD CLAMP NUT
13	06655	LOCK RING
14	06520	PIN, 1/8 X 1/4
15	06609	O-RING
16	06510	BALL BEARING 3/8 X 7/8 X 9/32
17	06639	FRONT END PLATE
18	06562	ROTOR
19	06643	VANE, SET
20	06563	CYLINDER
21	06560	REAR END PLATE
22	06527	WAVE WASHER .440 X .618 X .008
23	06508	BALL BEARING
24	06567	WASHER .251 X .468 X .063
25	06568	SCREW #8-32 X 3/8 BUT HD CAP
26	06638	HOUSING
27	06558	TORR PIN, 3/16 X 7/8
28	06543	O-RING
29	06511	O-RING
30	06556	REGULATOR
31	06501	SCREW, 6-32 X 3/4 SET SOC HEX
32	06598	HOUSING COVER
33	06642	LEVER
34	06559	GROOVE PIN, 1/8 X 7/8 TYPE E
35	06566	WARNING LABEL
36	06557	MUFFLER
37	06552	THROTTLE VALVE SEAT
38	06553	THROTTLE VALVE
39	06554	TAPER SPRING
40	06555	SCREEN
41	06608	O-RING, 1/16 X 5/8 X 3/4
42	06604	ROTATABLE EXHAUST DEFL ECTOR
43	06605	INLET BUSHING
44	06586	7/16" X 11/16" WRENCH

PN20232
PN25125



21 06560 REAR END PLATE
22 06527 Wave Washer
.440" x .618" x .008
23 06508 Ball Bearing