

Item	Part	Description
12	9510009	Belleville washer
7	9510012	Screw M4x16 TCC
15	9510015	Screw 4,2x25 TCC
17	9510020	WASHER
18	9510021	Steel spacer $\varnothing 18 \times \varnothing 9,1 \times 0,15$
19	9510022	Washer
20	9510023	Shaft preload spring
23	9510031	Bearing
6	9510032	Side handle MLH18/MGL125
24	9510033	Diffuser
27	9510034	Rubber bearing support SH 45-50
28	9510035	Motor body MLH18
31	9510036	Brush holder
33	9510037	Screw 2,9x13 TCC
26	9510038	Screw 2,9x70 TCC
30	9510039	Brush holder plate
32	9510041	Brush holder spring
29	9510044	Brush
37	9510047	Cord protector
36	9510048	Main switch
38	9510049	Trigger for MLH18
35	9510050	Top handle cover MLH18/MGL125
40	9510051	Screw 3,9x16 TCC
41	9510053	Cord grabber
43	9510058	Locking Key 17mm
8	9530007	Gear flange
9	9530009	Spindle
39	9530020	Lower handle cover MLH18/MGL125
25	9550001	Stator 230V (110V)
11	9550002	Bearing
22	9550003	Steel spacer $\varnothing 15 \times \varnothing 6,1 \times 0,15$
10	9550004	Spacer
1	9550005	Screw M8x20 TE
13	9550006	Crown gear
16	9550007	Locking ring for bearing
2	9550008	Spacer for sanding tool
43	9550009	Locking Key 11 +13mm
34	9550010	Electronic speed control 230V
4	9550011	Shaft
5	9550012	Safety guard
43	9550013	Locking Key 19mm
21	9550014	Rotor 230V (110V)
14	9550015	Gearbox with button lock MSR
3	9550017	Inflatable rubber sanding dome
42	9550018	Cord DE 230V

PN64999

