

Item	Part	Description	PN28737
01	66856	THROTTLE HANDLE	
02	66857	THROTTLE VALVE	
03	66858	VALVE STEM	
04	66859	O-RING	
05	66860	VALVE SPRING	
06	66861	AIR REGULATOR	
07	66862	O-RING (2)	
08	66863	O-RING (2)	
09	66864	MUFFLER FELT	
09-1	66865	MUFFLER FELT	
10	66866	MUFFLER PLATE	
11	66867	AIR INLET BUSHING	
12	66868	ROTOR	
13	66869	SPACER	
14	66870	FRONT END PLATE	
15	66871	SPRING PIN (3)	
16	66872	BALL BEARING	
17	66873	BEVEL PINION	
18	66874	CYLINDER	
19	66875	ROTOR BLADE (4)	
20	66876	REAR END PLATE	
21	66877	BALL BEARING	
22	66878	ARBOR CASING	
23	66879	OILER	
24	66880	ARBOR	
25	66881	BALL BEARING	
26	66882	BEVEL GEAR	
27	66883	BALL BEARING	
28	66884	WAVE WASHER	
29	66885	DUST SEAL	
30	66886	ARBOR BEARING CAP	
31	66887	LOCK NUT	
32	66888	COUNTERWEIGHT	
33	66889	SET SCREW	
34	66890	BALANCE SHAFT	
35	66891	BALL BEARING (2)	
36	66892	SNAP RING (2)	
37	66893	HEX. SOCKET BUTTON HEAD SCREW	
38	66894	BOOT	
39	66895	BOOT CLAMP	
40	66896	GRIP	
41	66897	THROTTLE LEVER	
42	66898	SPRING PIN	
43	66899	ROLOC PAD MOUNTING SPINDLE	
44	66900	HEX. SOCKET BUTTON HEAD SCREW (4)	
45	2345	32 mm (1 1/4) ROLOC™ PAD PSA, MEDIUM	
46	66901	L SHAPE HEX. WRENCH (2,5 mm)	
47	66902	L SHAPE HEX. WRENCH (2,0 mm)	
48	66903	SPACER (Ø17 mm X Ø21,8 mm X 0,05	
49	66904	SPACER (Ø26 mm X Ø29,5 mm X 0,05	
50	66905	HANGER	
51	66906	BUTTON HEAD SCREW (2)	
51	66906	BUTTON HEAD SCREW	

