

Item	Part	Description
1	30611	HOUSING - LEFT
2	30612	SOCKET BUTTON HEAD CAP SCREW -
3	30613	MOTOR CASE
4	30614	O-RING - 31 MM X 34 MM
5	30615	O-RING - 8 MM X 10 MM
6	30616	HOUSING - RIGHT
7	30617	TRACKING / CONTROL KNOB
8	30618	SOCKET HEAD CAP SCREW - M3 X 5
9	28368	FILE BELT ARM STANDARD STYLE
9	28369	FILE BELT SANDER ATTACHMENT ARM.
9	28370	FILE BELT SANDER ATTACHMENT ARM.
9	28371	FILE BELT SANDER ATTACHMENT ARM.
9	28372	FILE BELT SANDER ATTACHMENT ARM.
9	28373	FILE BELT SANDER ATTACHMENT ARM.
9	28374	FILE BELT SANDER ATTACHMENT ARM.
9	28375	FILE BELT SANDER ATTACHMENT ARM.
9	28376	FILE BELT SANDER EXTENSION
11	30620	TRACKING ARM MOUNT
12	30621	SPRING - BELT TENSION
13	30622	TRACKING ARM POST
14	A0767	FLAT HEAD SCREW - M4 X .07 10 MM
15	30624	DUST COVER
16	30625	BELT COVER AND LATCH ASSEMBLY
17	30626	DRIVE STUD ADAPTOR
18	A0021	BEARING - 2 SHIELDS 10 MM X 26 MM
19	30628	SHIM - 25.4 MM OD X 19 MM ID X
20	30629	SHIM - 25.4 MM OD X 19 MM ID X
21	30630	SPACER - 13.4 MM OD X 10.01 MM ID
22	30631	ENDPLATE ASSEMBLY - FRONT
23	30632	CYLINDER
24	30633	ROTOR
25	30634	ROTOR VANE SET
26	30635	ENDPLATE ASSEMBLY - REAR
27	30636	BEARING - 2 SHIELDS 6 MM X 19 MM X
28	30637	BELT HOUSING/GUARD
29	30638	DRIVE PULLEY
30	30639	FRONT EXHAUST MANIFOLD
31	30640	DIFFUSER
32	30641	MOTOR SPACER
33	30642	AIR GUIDE
34	30643	GASKET, AIR GUIDE
35	30644	HANDLE GRIP
36	30645	HANDLE
37	30646	RETAINING RING - 7/16 IN. DIAMETER
38	30647	VALVE STEM
39	30648	O-RING - 4 MM X 1.0 MM
40	30649	SAFETY LEVER ASSEMBLY SET
41	30650	SPRING PIN
42	30651	SPEED CONTROL
43	A0043	O-RING - 9 MM X 1.5 MM (IDENTIC
44	30653	VALVE SEAT
45	30654	VALVE
46	A0014	VALVE SPRING (IDENTIC WITH PART
47	30656	RETAINING RING - 5/8 IN. DIAMETER
48	30657	DIFFUSER
49	30658	EXHAUST CAP WITH LABELS
50	30659	O-RING - 15.6 MM X 1.5 MM
51	30660	WASHER, AIR INLET
52	30661	INLET ADAPTOR
53	30671	DRIVE PULLEY - RUBBER
54	30672	WRENCH - DRIVE WHEEL
55	30674	WRENCH - 2.5 MM L-KEY
56	30673	WRENCH - 4.0 MM L-KEY

## PN28366







